


SE7510

Digital Weight Indicator

Operating Manual



Edition:01-081008

LOADMASTER Scale Mfg

420 E. Lincoln St., Findlay, Ohio 45840 Phone:800-637-3326

1. Calibration operation

1.1 Calibration and key function in application

In order to make the operation simpler, there are many arrow key below each key for some meaning.



Back: back to last step



Exit: back to the main menu.



Left: move cursor to left



Right: move cursor to right



Up: Add value or choice up



Down: Decrease value or choice down





Enter: confirm and go to next step


1.2 Calibration

Before calibration. Pls. make sure the indicator switch CAL is on. The connection between load cell and indicator is ok. and scales calibration is ok.

1.2.1 Calibration menu



Press **total** and **print** until display C01



Press **print** [C1 1]. Use ↑ ↓ to choose the unit

Optional unit:

[C1 1] = kg

[C1 2] = lb



Press **print** enter to C02

C02 Decimal points setting C02

print

Press **print** go to [0] choose the decimal digits. Use ↑ ↓

to choose the decimal digits.

optional decimal digits:

[0] = no decimal point

[0.0] = one decimal point

[0.00] = two decimal point

[0.000] = three decimal point

[0.0000] = four decimal point

print

Press **print** go to next step [C03]

C03 Division setting.

print

Press **print** go to [C3 1]. Set the division. Use ↑ ↓ choose

the division needed.

Optional division:

[C3 1] division = 1

[C3 2] division = 2

[C3 5] division = 5

[C3 10] division = 10

[C3 20] division = 20

[C3 50] division = 50

print

Setting finish, press **print** and save setting. Enter to [C04]

C04 Max. capacity choose C04

 print

Press  go to [000000] set the max.. capacity. Use \leftarrow \rightarrow

Shift the cursor. And \uparrow \downarrow to adjust the value. Finish the setting and

 print

press  go to next step [C05].

C05 Dead load calibration

 print

Press  enter [C5 0]. Giving up the dead load calibration or perform the dead load calibration. And use \uparrow \downarrow to adjust the value.

Optional result:

[C5 0] no empty scales calibration

[C5 1] perform dead load calibration

Confirm performing dead load calibration. Pls. empty scales firstly. Set [C05 1]

 print

Press . Display [CAL 10]----[CAL 0]. Calibration count down.

 print

Then. Display [0.00] (two decimal points means ok) Press 

enter [C06]

C06 Capacity span calibration

 print

Press  enter [C6 0]. Choose capacity span calibration. Use

\uparrow \downarrow to choose whether perform the capacity span calibration.

Option

[C6 0] No capacity calibration

[C6 1] Perform capacity span calibration

Confirm to perform the capacity span calibration. Set [C6 1]. Add the weight on the scales. recommend use weights above 60% of the Max. capacity.



Press

Display [SPAN] firstly. Then display[000000].

capacity. Use ← → Shift the cursor. And ↑ ↓ to adjust the weights.



Press

Display [CAL 10]----[CAL 0]. Capacity calibration

count down. When the count down finish. Display the weight of the added weights. Calibration is over.



Press

enter [C07]. If you want to exit. Press



then

back to weighing status.

Note: when calibration is finish. Pls. turn the CAL to off position.

2. Application environment parameter setting

After calibration. if not exit You could go on with [C07] setting



If already exit the menu. Press **total** and **print** go to parameter setting menu. use ↑ ↓ to adjust the parameter to [C07].

C07 Zero setting range

 zero

Press the  key or the option function I/O card to connect the zero signal and set the gross weight in the acceptable arrange to zero

 print

Press  enter [C7 0]. Choose the zero arrange. Use ↑ ↓ to select the range.
option:

- [C7 0] = no initial zero setting
- [C7 2] = 2% Max. capacity
- [C7 4] = 4% Max. capacity
- [C7 5] = 5% Max. capacity
- [C7 10] = 10% Max. capacity
- [C7 20] = 20% Max. capacity

 print

Press  to save the setting. Enter [C08]

C08 Initial zero setting range

When switching on the indicator, the gross weight within the initial zero setting range can be zero automatically.

 print

Press . Enter [C8 0]. And choose the initial zero setting range. Use ↑ ↓ to select the range

Initial zero setting range:

- [C8 0] = no initial zero setting
- [C8 2] = 2% Max. capacity
- [C8 4] = 4% Max. capacity
- [C8 5] = 5% Max. capacity

[C8 10] = 10% Max. capacity

[C8 20] = 20% Max. capacity

 print

Press  . Save the setting. Enter [C09]

Note: Initial zero range can not bigger than zero setting range

C09 Automatic zero tracking range

Automatic zero tracking range is for compensating the change caused by temperature or by the little missed material on the scales. It take the d as the basic unit for setting.

=

 print

When in [C09] menu. press  enter [09 0.5]. choose the automatic zero tracking range. Use ↑ ↓ to select the range

Options:

[C9 0.0] = no initial zero setting

[C9 0.5] = ±0.5d

[C9 1.0] = ±1.0d

[C9 1.5] = ±1.5d

[C9 2.0] = ±2.0d


[C9 2.5] = ±2.5d


[C9 3.0] = ±3.0d

[C9 3.5] = ±3.5d

[C9 4.0] = ±4.0d

[C9 5.0] = ±5.0d

 print

Press  . Save the setting. Enter [C10].

Note: Initial zero range can not bigger than zero setting range

C10 Automatic zero tracking time

Automatic zero tracking time determine the time interval between the two times automatic zero tracking.

print

When in [C 10] menu. Press enter[C10 1]

select the automatic zero tracking time. Use ↑ ↓ to select the range

Time setting options

[C10 0] = no automatic zero tracking time

[C10 1] = 1 second

[C10 2] = 2 seconds

[C10 3] = 3 seconds

print

Press . Save the setting. Enter [C11].

C11 Overload range

Over load range take d as the basic unit

print

When in [C 11] menu. Press enter [C11 09]

Use ← → Shift the cursor. And ↑ ↓ input the overload range.

Over load range: 0~99d

[C11 00] =no overload range

•

•

•

[C11 99] = means 99d

print

Press . to save the setting. Enter [C12].

C12 Negative display range

Set the indicator negative display range. Negative display range 0 means basic setting unit is "d". and set other options % Max. capacity.

print

When in [C12] menu. Press  enter [12 10]. Use $\leftarrow \rightarrow$ Shift the cursor. And $\uparrow \downarrow$ input the negative display range.

Negative display range:

[C12 0] = -9d

[C12 10] = 10% Max. capacity

[C12 20] = 20% Max. capacity

[C12 50] = 50% Max. capacity

[C12 99] = 100% Max. capacity

print

Press  to save the setting. Enter [C13].

C13 Digital filter 1

The value bigger, the digital filter is stronger and data is more stable. But the update time is slower.

print

In [13] status. Press  enter [C13 3]. Use $\uparrow \downarrow$ input the digital filter option.

Digital filter 1 option

[C13 0] = close digital filter 1

[C13 1] = 1 digital filter strength

[C13 2] = 2 digital filter strength

[C13 3] = 3 digital filter strength

[C13 4] = 4 digital filter strength
[C13 5] = 5 digital filter strength
[C13 6] = 6 digital filter strength

print

Press  save the setting. Enter next step [C 14]

Note: Don't set the digital filter 1 in normal weighing. It only for animal weighing or other goods in moving. Refer to the Animal scales operation in user's manual.

C14 Digital filter 2

print

In [C14] status, press  enter [C14 2]. Use ↑

↓ input the digital filter option.

Option for digital filter 2

[C14 0] = close digital filter 2
[C14 1] = 1 digital filter strength
[C14 2] = 2 digital filter strength
[C14 3] = 3 digital filter strength

print

Press  to save the setting. Enter next step [C 15]

C15 Standstill time

Determine the time of the scales from moving to standstill Status within the standstill range.

print

In [C15] status. Press  enter[C15 1], Use ↑ ↓

input the options

Standstill time options:

- [C15 0] = close the standstill time
- [C15 1] = 1 second
- [C15 2] = 2 seconds

C16 Standstill range

Standstill range determine when the scales is in standstill status. when the scales not in standstill status. zero. Tare and print operation is prohibited.

C17 Power saving mode

For power saving, weight keep stable till no any change for the Automatic shutting off time. The indicator will show shut off automatically. Press any key or change the weight can wake up the indicator display.



In [17] status. Press enter to [C17 0]. Use ↑ ↓ input the options needed.

Automatically shut off time options:

- [C17 0] = shut off the saving power mode
- [C17 1] = 3 minutes
- [C17 2] = 5 minutes



Press to save the setting. Go to next step [C18]

C18 Reserved and no function



Press and go to next step [C 19]

C19 Reserved and no function




print


Press  and go to next step [C 20]

C20 Open Upper limit alarm value

Set the upper limit alarm value and lower limit alarm value can control the I/O card output signal.



print

In [C 20] status. Press  enter [0000.00]. Use \leftarrow \rightarrow

Shift the cursor. And \uparrow \downarrow input the open upper limit alarm value.

Setting range: Random setting within the full range



print

Setting finish then press  to save the it. Go to next step

[C21]

C21 Shut off Upper limit alarm value




print


In [C21] status. press  enter[0000.00] and Use \leftarrow \rightarrow

Shift the cursor. And \uparrow \downarrow input stop the upper limit alarm value.

Setting range: Random setting within the full range.



print

Setting finish then press  to save the input setting. Go to next step [C22]

C22 Open lower limit alarm value



print

In [C22] Status. Press  go to [0000.00]. and Use \leftarrow

→ Shift the cursor. And ↑ ↓ input the upper limit alarm on value.
Setting range: random setting within full range



Setting finish. Press and save the setting. Go to next step [C23]

C23 Lower limit alarm off value



In [C23] status. press go to [0000.00] and Use ← →

Shift the cursor. And ↑ ↓ input the upper limit alarm off value.

Setting range: random setting within full range



Setting finish. Press and save the setting. Go to next step [C24]

Note: upper limit alarm and lower limit alarm value setting method refer to “ classifying scales operation” in the “ user's manual”.

C24 Reserved and no function



Press and go to next step [C 25]

C25 Reserved and no function



Press and go to next step [C 26]

C26 Reserved and no function



Press and go to next step [C 27]

C27 Serial interface data output method

When the indicator equipped with RS232. RS232 interface connect different serial interface communication terminals equipment, set serial interface data output method.

print

In [C27] in statue, press  enter [C27 0]. Go to data output setting. Use ↑ ↓ to set input and output data

Data output options

[C27 0] =Close serial interface data output

[C27 1] = Continuous sending (connect big display)

[C27 2] = Printing method, (connect the printer)

[C27 3] = Command request method (connect computer)

print

Press , save the setting and go to next step[C28]

C28 Serial interface baud rate.

Baud rate is the information sending speed. And when RS232 interface connect with different serial interface communication terminals. The baud rate should keep the same.

print

In [C28] status, press  enter [C28 3]. Choose serial interface baud rate. Use ↑ ↓ input the serial interface.

C29 Bit and parity

print

In [C29] status, Press  go to [C29 0], Set bit and parity, Use ↑ ↓ input the bit and parity

Option:

- [C29 0] = 8 bit, none parity (8, none)
- [C29 1] = 7 bit, even parity (7, even)
- [C29 2] = 7 bit, odd parity (7, odd)



Press . Save setting. And go to next step[C30]

C30-C37 Reserved and no function



Press and go to next step [C 38]

C38 Date

According to the user's need, if connect with printer, we need update the date in the first time and every time restart it



In [C38] status, Press go to [000000], setting the date.

and Use ← → Shift the cursor. And ↑ ↓ input year, month and day,

C39 TIME

Real-time clock settings can be set: hours, minutes and seconds



In [C 39] statue, press go to [000000], setting the time.

and Use ← → Shift the cursor. And ↑ ↓ input hours. Minutes and seconds

for example: the time is:15:28:30 then set [152830]



after setting finish. Press and save the input time. Go to next step[C40]

C40 To restore the default values

print

In [C40] statue, press  go to [C40 0], restore the default values. Use ↑ ↓ input the options

Options:

[C40 0]= NO restore default value

[C40 1]= Restore default value

print

After finish it, if confirm to restore default value. Press 

Indicator will automatically restore all the parameter to the original default value.

Note: Pls. not restore the default value without the professional technicians and calibration.

Default value

parameter	instruction	Default value
C01	Calibration unit	1
C02	Decimal digits	0
C03	resolution	1
C04	Max. capacity	10000
C05	Empty scales calibration	0
C06	Capacity calibration	0
C07	Zero setting range	2
C08	Initial zero setting range	2
C09	Automatic zero tracking range	0.5
C10	Automatic zero tracking time	1
C11	Overload range	9
C12	Negative display range	10
C13	Digital filter 1	0
C14	Digital filter 2	2
C15	Standstill time	1
C16	Standstill range	2
C17	Power saving mode	0
C20	Upper limit alarm on value	000000
C21	Upper limit alarm off value	000000
C22	Lower limit alarm on value	000000
C23	Lower limit alarm off value	000000
C27	Communication protocol of Serial interface	0
C28	Baud rate of serial interface	3
C29	Bit and parity	0
C38	Date	000000
C39	Time	000000
C40	Default parameter	0

Default value

parameter	instruction	Default value
C01	Calibration unit	1
C02	Decimal digits	0
C03	resolution	1
C04	Max. capacity	10000
C05	Empty scales calibration	0
C06	Capacity calibration	0
C07	Zero setting range	2
C08	Initial zero setting range	2
C09	Automatic zero tracking range	0.5
C10	Automatic zero tracking time	1
C11	Overload range	9
C12	Negative display range	10
C13	Digital filter 1	0
C14	Digital filter 2	2
C15	Standstill time	1
C16	Standstill range	2
C17	Power saving mode	0
C20	Upper limit alarm on value	000000
C21	Upper limit alarm off value	000000
C22	Lower limit alarm on value	000000
C23	Lower limit alarm off value	000000
C27	Communication protocol of Serial interface	0
C28	Baud rate of serial interface	3
C29	Bit and parity	0
C38	Date	000000
C39	Time	000000
C40	Default parameter	0